


951 950 ST VKR OPTION ASSEMBLY INSTRUCTIONS





ParaBody, Incorporated 14150 Sunfish Lake Boulevard Ramsey, MN 55303 1-800-328-9714

Part # 6642001


1

Revision: 07/17/96

951101 950 ST VKR DIP OPTION ASSEMBLY PARTS LIST

SORT AND COUNT ALL PARTS BEFORE BEGINNING ASSEMBLY

QTY		NAME/DESCRIPTION	KEY
1	(6625603)	VKR FRAME	1.
1	(6625703)	VKR FRAME SUPPORT	2.
1	(6625802)	VKR FOOT STEP	3.
1	(6177001)	STRIP, NON-SKID	4.
3	(6405201):	CAP, END 2 SQ	5.
4	(3103101)	GRIP, 1-1/4 X 5 CLOSED END	6.
10	(3102501)	WASHER, FLAT 3/8 ID	7.
		WASHER, FLAT 1/2 ID	8.
		NUT, NYLOCK 3/8-16	9.
		NUT, NYLOCK 1/2-13	10.
		BOLT, 3/8-16 X 2-3/4	11.
		BOLT, 3/8-16 X 3	12.
		BOLT, 1/2-13 X 4	13.
			14.
			15.
•••	(66410XX)(66414XX)	PAD, STCH 22 X 10-1/2PAD, STCH 14 X 4-1/2PAD, STCH 14 X 4-1/2	14. 15.



BOLT LENGTH RULER:

	1/2	1/2	1/2	1/2	1/2	1/2
0	1 1	1 :	2 :	3 '	4 :	5 6


THANK YOU

FOR PURCHASING THE 951101 VKR/DIP OPTION ATTACHMENT. PLEASE SAVE THESE ASSEMBLY INSTRUCTIONS FOR YOUR PERSONAL REFERENCE, AND ADDITIONAL SERVICE INFORMATION.

IMPORTANT


- PARABODY INC. STRONGLY RECOMMENDS THAT THIS PRODUCT BE ASSEMBLED BY TWO PERSONS TO AVOID POSSIBLE INJURY.
- IF YOU EXPERIENCE ANY PROBLEM WITH THE ASSEMBLY OF THIS PRODUCT, PLEASE CONTACT YOUR DEALER OR YOUR PARABODY CUSTOMER SERVICE REPRESENTATIVE AT: 1-800-328-9714
- TOOLS REQUIRED: RATCHET, 3/4 SOCKET, 9/16 SOCKET, WRENCH, AND RUBBER MALLET OR HAMMER.

VKR Uption Assembly Instructions
Use this procedure to assemble the 951 VKR option to the ParaBody 950 ST.



Step 1

- A. Insert two 2" sq. end caps (5) into the ends of the VKR frame (1) as shown on drawing.
- B. Insert one 2" sq. end cap (5) into the end of the VKR foot step (3) and apply one non-skid strip (4) as shown.
- C. Slide four 1-1/4" grips (6) onto the handles of the VKR frame (1).





Step 2


- Securely attach two arm pads (15) to the VKR frame (1) using four $3/8 \times 2-3/4$ ° bolts (11) and four 3/8° washers (7).
- B. Securely attach back pad (14) to the VKR frame support (2) using two $3/8 \times 2-3/4$ " bolts (11) and two 3/8" washers (7).

Step 3

A. Loosely assemble the VKR frame support (2) to the VKR frame (1) using two 3/8 x 3" bolts (12), four 3/8" washers (7), and two 3/8" nylock nuts (9). (Note: This connection will be secured in STEP 4-B.)







Step 4

- A. Securely assemble the VKR frame (1) and the VKR frame support (2) to the rear upright of the 950 ST GYM as shown using four $1/2 \times 4$ " bolts (13), four 1/2" washers (8), and four 1/2" nylock nuts (10).
- B. Securely tighten the VKR frame (1) and VKR frame support (2) connection.
- C. Securely attach the VKR foot step (3) to the rear upright of the 950 ST GYM as shown in drawing, using two $1/2 \times 4$ " bolts (13), two 1/2" washers (8), and two 1/2" nylock nuts (10).

4